



Configuration using one tower.

Cooling Mode - Using the evaporative cooling tower in a closed loop circuit. Check Flow and the Dump Flow switch will close. Evaporative pump and fan will run when one or both Geo units are on.

Heating Mode - Flow switch to the tower will close, tower pump & fan will not run, By-passing the tower, pull from the wells only and discharge. Well Check Flow switch and the Dump Flow switch will open.

- Check Valves
- Flow Switch
- Check Flow Switch